

GM Factory Window Part # 84819603



Overhead assembly with rear sliding window switch; several variations available (HomeLink, Sunroof ect.) Choose which suites your needs best. These can be found on Ebay.



Relays in place

Wiring may not look as clean as factory installed but once covered who is gonna know is even there.

Additional parts needed:

22774498 Switch (If your overhead console assembly didn't include one)

ACDelco PT796 Pigtail for the switch

5 Pole NC/NO Relay x2