


Lower LR of the Engine Components (4.8L/5.3L/6.0L)



- (1) Ground 103 (G103)
- (1) Ground 103 (G103)
- (2) Engine Harness- H02S
- (3) HO2 Sensor connector- Bank 1, Sensor 1
- (4) Fuel Line Bracket
- (5) Ground 104 (G104)
- (5) Ground 104 (G104)
- (6) Oil Pressure Sensor Connector
- (6) Oil Pressure Sensor
- (7) Engine Ground Strap (G107)
- (8) TP 1 Battery Cable (G106)

© 2014 General Motors Corporation. All rights reserved.