


LR of the Engine Compartment -- Bulkhead Components



- (1) Windshield Wiper Motor Module Electrical Connector
- (2) Cruise Control Module (CCM) Electrical Connector
- (3) Plenum Panel
- (4) Cruise Control Module (CCM)
- (5) Pass-Through 100 (P100)
- (6) Dash Panel
- (7) Cap For Connector (Without Cruise Control)
- (8) Cruise Control Module (CCM) Electrical Connector
- (9) Harness Pass-Through
- (10) Windshield Wiper Motor Module